


SC200A


		Name	
1	51320-G6C5-00B4	HANDGRIP COMP	1
2	52000-G5C5-1400	COMTROL PANEL COMP	1
3	51310-G5C5-0000	WHEEL COMP	2
4	51100-G5C5-002B4	FRAME COMP	1
5	20044-00079-00	AVR	1
6	51206-G5C5-00B4	ENGINE HOOD	
7	54100-G5C5-02RE	TANK ASSY, FUEL	1
8	B5789-06KG-025B	BOLT, FLANGE M6	4
9	B5287-G7A2-000B	WASHER, TANK CUSHION	4
10	54105-G5AA-0000	COCK ASSY, FUEL	1
11	B5787-06KG-012B	BOLT, FLANGE M6	10
12	53207-G6C5-00B4	SIDE PANEL	1
13	B5789-10LG-257C	BOLT, FLANGE M10	1
14	B97.4-105G-000B	FLAT WASHER	1
15	10000-E90C-A002	ENGINE ASSY	1
16	11200-E90C-0000	COVER, CRANKSHAFT	1
17	20029-05316-00	ALTERNATOR COMP	1
18	31502-B140-0013	BRACKET, ALTERNATOR	1
19	B6177.1-10LG-000B	BOLT, FLANGE M10	4
20	B5787-06KG-185C	BOLT, FLANGE M6	4
21	31301-B148-0007	END COVER, ALTERNATOR	1
22	B5787-05JG-012B	BOLT, FLANGE M5	5
23	51204-G5A3-A000	RUBBER SEAT A	4
24	51330-G5C5-00B4	SUPPORT COMP	2
25	B6177.1-06KG-000B	BOLT, FLANGE M6	5
26	51304-G5A3-0000	RUBBER SEAT, SUPPORT	2
27	B5789-06KG-020B	BOLT, FLANGE M6	2
28	12026-G5D8-0000	RECTIFIER COMP	1
29	15005-G5D8-0000	RADIATOR	1
30	51229-G6C5-0000	DOWEL PIN, HANDGRIP	2
31	51306-G5D8-0000	RUBBER SLEAVE, HANDGRIP	1
32	51301-G6C5-0000	SHAT COMP, WHEEL	2
33	16006-G7A2-0000	CLIP PIN	2
34	11013-E88F-0000	CLIP, WIRE	2
35	11202-E90F-0000	DUSTPROOF BLOCK, CRANKSHAT COVER	1
36	B5789-06KG-020B	BOLT, FLANGE M6	2
37	B895-085G-000C	SPRING WASHER	2
38	B6170-0800-000C	HEX NUT M8	2
39	18010-E88F-0000	WASHER, MUFFLER	1
40	53100-G5AA-02W4	MUFFLER COMP	1
41	12027-G5D8-0000	CHARGING COMP	1
42	51202-G5A1-02B4	TENSION PLATE, BATTERY	1
43	51270-G8A2-0000	BATTERY 12V/18Ah	1
44	51217-G6A3-450B	NAGETIVE WIRE, CHARGE	1
45	51217-G6A3-340R	POSITIVE WIRE, CHARGE	1
46	51312-G7C5-0000	PLUG, FRAME	2
47	53217-G5A1-000C	SUPPORT, MUFFLER	1
48	55005-G5A3-0000	RUBBER, DUSTPROOF	1
49	55017-G5C6-0000	WIRE, COVER	1
50	B70.1-05KG-016B	CAP SCREWS, HEX SOCKET DEAD	2
51	B5789-06KG-012C	BOLTS, FLANGE M6	2
52	B5787-05KG-225B	BOLTS, FLANGE M5	2
53	B5787-08LG-16B	BOLTS, FLANGE M8	4
54	B5787-06KG-016B	BOLTS, FLANGE M6	8
55	B5787-05JG-016B	BOLT, FLANGE M5	1
56	B5787-08LG-040B	BOLT, FLANGE M8	1
57	B6177.1-08KG-000B	BOLTS, FLANGE M8	5
58	B95-016G-000B	FLAT WASHER	2



Explosive view of SC200A


E-01	Cylinder head.....	2~3	E-06	Carburetor.....	10
E-02	Crankcase assy.....	4~5	E-07	Recoil starter.....	11~12
E-03	Crankcase cover.....	6	E-08	Speed Control System.....	13
E-04	Crankshaft piston.....	7	E-09	Flywheel.....	14
E-05	Camshaft	8~9	E-10	Air cleaner.....	15

E-01 Cylinder head




NO.	Part NO.	Description		QTY
		English		SC200A
1	30101-00071-01	BOLT,M6×20		4
2	20021-00018-00	COVER COMP.HEAD		1
3	30101-00280-00	BOLT,M6×12		5
4	34021-00014-01	WIND GUIDER		1
5	33048-00154-01	GASKET,HEAD COVER		1
6	30101-00289-01	BOLT		4
7	30110-00027-01	BOLT,STUD,EXHAUST		2

E-01 Cylinder head




NO.	Part NO.	Description		QTY
		English		
8	20027-00011-00	SPARK PLUG		1
9	34006-00007-00	DOWEL PIN		2
10	33048-00035-00	GASKET,HEAD COVER		1
11	30110-00021-01	BOLT,STUD,INTAKE		2
12	20023-00035-00	CYLINDER HEAD COMP		1
13	34021-00062-01	SHROUD		1
14	34023-00074-01	TUBE,BREATHER		1
15	34024-00056-01	CLIP,FUEL PIPE		1

E-02 Crankcase assy




NO.	Part NO.	Description		QTY
		English	SC200A	
1	30101-00277-00	BOLT	2	
2	33247-00010-01	ENGINE OIL SENSOR	1	
3	30141-00112-00	BEARING	1	
4	34026-00005-01	SHAFT,GOVERNOR	1	
5	34007-00002-01	OIL SEAL	1	
6	34006-00017-00	PIN, LOCK	1	
7	30136-00097-00	WASHER	2	
8	30101-00297-00	BOLT	2	
9	20149-00009-01	Start motor	1	

E-02 Crankcase assy




NO.	Part NO.	Description		QTY	
		English		SC200A	
10	20009-00030-01	Charging coil		1	
11	30101-00514-01	BOLT		2	
12	30136-00080-01	WASHER		2	
13	33593-00007-01	Wire pressing board		1	
14	30101-00281-00	BOLT		3	
15	30101-00284-00	BOLT		1	
16	34007-00012-01	OIL SEAL		1	
17	34011-00037-00	CRANKCASE		1	
18	20249-00002-01	SPORT MEMBE		1	

E-03 Crankcase cover




NO.	Part NO.	Description		QTY	
		English		SC420	
1	34007-00012-01	OIL SEAL		1	
2	30101-00280-00	BOLT		10	
3	20026-00004-02	DIPSTICK ASSY		1	
4	20013-00004-01	GOVERNOR GEAR KIT		1	
5	33048-00064-01	GASKET,CRANKCASE COVER		1	
6	34006-00001-00	DOWEL PIN		2	
7	30141-00112-00	BEARING		1	
8	30141-00117-00	BEARING		1	
9	33129-00018-00	CRANKCASE COVER		1	

E-04 Crankshaft piston




NO.	Part NO.	Description		QTY
		English		
1	20084-00009-00	RING SET,PISTON		1
2	30150-00023-00	CLIP,PISTON PIN		2
3	34004-00016-00	PISTON		1
4	34006-00015-00	PIN,PISTON		1
5	20008-00008-00	CONNECTING ROD ASSY		1
6	20011-00048-00	CRANKSHAFT ASSY		1

E-05 Camshaft




NO.	Part NO.	Description		QTY
		English		
1	30110-00034-01	NUT, VALVE ADJUSTING		2
2	30134-00005-01	ROCKER SHAFT		2
3	34019-00005-00	ROCKER ARM		2
4	30121-00033-01	BOLT VALVE		2
5	34017-00008-00	PLATE, PUSH ROD GUIDE		1
6	33141-00022-00	ROTATOR, VALVE		2
7	34016-00007-00	RETAINER, VALVE SPRING		2
8	34015-00004-00	SPRING, VALVE		2

E-05 Camshaft




NO.	Part NO.	Description		QTY
		English		
9	34016-00008-00	RETAINER,VALVE BOTTOW		2
10	34018-00001-01	OIL SEAL		2
11	34013-00032-00	VALVE,EXHAUST		1
12	34013-00052-00	VALVE, INTAKE		1
13	34020-00010-00	PUSH ROD		2
14	34008-00006-00	LIFTER, VALVE		2
15	20012-00015-00	CAMSHAFT,ASSY		1
16	34033-00001-00	BALANCE SHAFT		1

E-06 Carburetor




NO.	Part NO.	Description		QTY	
		English		SC200A	
1	33048-00053-01	GASKET,INTAKE		1	
2	34012-00014-01	INSULATOR,CARBURETOR		1	
3	33048-00078-01	GASKET,CARBURETOR		1	
4	20024-00101-00	CARBURETOR		1	
5	33048-00047-01	GASKET,AIR CLEANER		1	
6	34024-00022-00	CLIP,FUEL PIPE		1	
7	34023-00004-01	FUEL PIPE		0.180m	
8	34024-00008-01	CLIP,FUEL PIPE		1	
9	34024-00009-01	CLIP,FUEL PIPE		1	

E-07 Recoil starter




NO.	Part NO.	Description		QTY
		English		
				SC200A
1	30101-00281-00	BOLT,M6×12		5
2	/	WIND GUIDER,RECOIL		1
3	/	SCREW,SETTING		1
4	/	SPRING,FRICITION		1
5	/	GUIDE,RATCHET		1
6	/	RATCHET,STARTER		2
7	/	SPRING,RETURN		2

E-07 Recoil starter




NO.	Part NO.	Description		QTY
		English		
8	/	REEL,RECOIL STARTER		1
9	/	SPRING,RECOIL STARTER		1
10	/	ROPE,RECOIL STARTER		1
11	/	COVER COMP		1
12	/	KNOB,RECOIL STARTER		1
13	/	BOLT,FLANGE		3
14	20010-00104-32	RECOIL STARTER COMP		1

E-08 Speed Control System




NO.	Part NO.	Description		QTY
		English		
1	20022-00018-01	SPEED CONTROL,ASSY		1
2	30101-00281-00	BOLT		2
3	34015-00020-01	SPRING,CABLE RETURN		1
4	34025-00007-01	HANDLE,SPEED CONTROL		1
5	34015-00010-00	SPRING,THROTTLE RETURN		1
6	34026-00008-01	ROD,GOVERNOR		1

E-9 Flywheel



NO.	Part NO.	Description		QTY	
		English		SC200A	
1	20028-00020-01	WIRE,ENGINE SWITCH		1	
2	30101-00283-00	BOLT,FLANGE		2	
3	33099-00020-00	FLYWHEEL COMP		1	
4	33155-00042-01	FAN COOLING		1	
5	34022-00008-01	PULLEY,STARTER		1	
6	30125-00035-01	NUT SPECIAL		1	
7	33246-00003-01	OIL ALARM		1	
8	30101-00281-00	BOLT,FLANGE		1	

E-10 Air cleaner



NO.	Part NO.	Description		QTY
		English	SC200A	
1	30125-00013-00	BOLT,FLANGE		2
2	/	ELEMENT ASSY,AIR CLEANER		2
3	/	COVER,AIR CLEANER		1
4	/	BOLT,FLANGE		6
5	/	SUPPORT,ELEMENT		1
6	/	BASE COMP,AIR CLEANER		1
7	20025-00083-01	AIR CLEANER ASSY		1
8	33015-00039-01	SLEEVE,FUEL PIPE		1